

## Primary & Comfort Heating For All Types of Floor Covering L a m i n a t e • T i l e

- Easy to install.
- Heats faster than any other Underfloor heating system.
- Perfect solution for home renovation as well as for new buildings.
- Creates pleasant warm feeling on your feet and in the room.

Can be installed **directly** in the tile adhesive, under the laminate floor.

The temperature in every room can be controlled separately by a thermostat



AHT UK  
Mobile: +44 7813 937360  
FAX: +44 1795 877232  
email: aht@aht-heating.com

Headquarters:  
7 Giborey Israel St.  
P.O.Box 8566, Industrial Zone,  
Netanya South, 42504 Israel  
Tel. +972-9-8357310  
Fax. +972-9-8650287  
e-mail: aht@aht-heating.com  
www.aht-heating.com

  
Advanced Heating Technologies Ltd.



© Copyright 2003

## Living Heat Living Heat Underfloor Heating

15  
YEAR  
WARRANTY





Advanced Heating Technologies Ltd.  
www.aht-heating.com



# Underfloor Heating For Laminate Tile Floors Easy as 1,2,3!


Use the following mat sizes to cover the floor area of your room

Living Heat

1. Lay the living heat mats on top of the underlay-insulated subfloor.



2. Connect the thermostat.



3. Install laminate floor directly on top of living heat mats.



4. Fix tiles directly over mats using flexible tile adhesive.



(In bathrooms - use grounding net on top of heating mat).

120 w/m<sup>2</sup>

0.5m width mats  
length: 1, 2, 3, 4, 5, 6m

1m width mats  
length: 1, 2, 2.5, 3, 4m

150w/m<sup>2</sup>

0.5m width mats  
length: 1, 2, 2.5, 3, 3.5, 4, 4.5, 5,  
5.5, 6, 6.5, 7m

1m width mats  
length: 1, 2, 2.5, 3, 3.5m

## Thermostat Options



MWTH

Living Heat

